

210.000 毫米

145.000 毫米



To qualify for the 2 year warranty the appliance must have been used according to the manufacturer's instructions. For example kettles should have been regularly de-scaled. If your appliance stops working or develops a fault then return it to your nearest store and we will happily replace or refund the item, with exception of the below exclusions:

- EXCLUSIONS**
- ASDA shall not be liable to replace goods under the terms of the warranty where:
1. The fault has been caused or is attributable to accidental use, misuse, negligent use or use contrary to the user manual's recommendations or where the fault has been caused by power surges or damage caused in transit.
 2. The appliance has been used on a voltage supply other than that described on the product rating label.
 3. Repairs have been attempted by persons other than our service staff (or authorized dealer).
 4. Where the appliance has been used for hire purposes or non-domestic use.
 5. ASDA are not liable to carry out any type of servicing work, under the warranty.

This warranty does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This warranty is offered as an additional benefit and does not affect your statutory rights as a consumer.

If for any reason this item is replaced during the 2 year warranty period, the warranty on the new item will be calculated from original purchase date. It is vital to retain your original proof of purchase to indicate the date of initial purchase.

Copyright


©2024 ASDA Stores Limited.
All other trademarks appearing herein are the property of their representative owners.
Specifications are subject to change without notice.
Produced for ASDA
Leeds LS11 5AD/ASDA
Antrim BT41 4GY

Disposal

This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the UK. For more information, please contact the local authority or your retailer, where you purchased the product.



George.
home



GHPTS041(B/CC) 4L

Primal soul Toaster User Guide

220-240V~ 50-60Hz 1930-2300W

IMPORTANT: RETAIN FOR FUTURE REFERENCE

1

About this guide

We've written this manual to help you get the most from your toaster. Please hold on to it for future reference.

WARNINGS:

THIS PRODUCT WAS DESIGNED AND MANUFACTURED TO MEET STRICT QUALITY AND SAFETY STANDARDS.THERE ARE, HOWEVER, SOME OPERATIONAL PRECAUTIONS YOU SHOULD BE AWARE OF.

CAUTION. DANGER OF BURNS. THE TOASTER MAY BECOME HOT DURING USE. DO NOT TOUCH HOT SURFACES. DANGER OF FIRE OR ELECTRIC SHOCK. DO NOT INSERT METAL FOIL, TOOLS, OR BREAD THAT IS TOO THICK INTO THE TOASTER.

1. Read all warnings & instructions in this manual to ensure you get the best out of your product.
2. Avoid outdoor and commercial use. This appliance is for household use only. Avoid bathroom use.
3. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.
4. ASDA does not recommend allowing children to operate this appliance.
5. Keep the appliance and its cord out of reach of

2

**100 DAY
SATISFACTION
GUARANTEE**

If for any reason you're not completely satisfied with our product, return it within 100 days with your proof of purchase, and we'll give you an exchange or a refund. UK Mainland stores only. Excludes franchises. The guarantee excludes flat pack furniture, which can't be returned if it has been partly or fully assembled unless faulty or mis-described. Also excludes mattresses, which can't be returned for hygiene reasons once used, unless faulty or mis-described.

For PDF copy of this manual please scan QR code and search for model number



Need something else?

www.GEORGE.com

We have a wide range of accessories and other products that can be ordered direct to your door.

ASDA
technical support
0333 600 7700

Customer services information

If you have any problems, need more information or spare parts, or even just some advice on your product, then don't hesitate to contact customer services at the telephone number or address shown opposite. N.B. When calling or writing please have your product site code handy.

Call
0800 952 0101

Write
ASDA, Leeds LS11 5AD

Product name: GHPTS041(B/CC) 4L

Product site code: 15A.06.34.081/15A.06.34.085

11

How to...

...clean your toaster

Make sure the toaster is disconnected from the power and is completely cool.

1. Use a damp cloth to clean the outside (don't use abrasive cleaners, as these can damage the surface of the toaster, or metal polish).
2. You should regularly pull out the crumb trays at the back of the toaster and dispose of the contents. This should be done once a week if the toaster is used regularly. Always make sure the trays are inserted back in properly before using the toaster.
3. When not in use or when placed in storage, the power cord should be wound under the bottom of the toaster.

How to...


...change the fuse

1. Only use a 10 amp fuse.

2. To change the fuse, place a screwdriver into the recess of the plug cover and pull the fuse holder upward until it's free.

3. Slide the fuse out and pop in the replacement.

4. Slot the fuse holder back into the recess and push down until it locks into place.



10

children less than 8 years.

6. The appliance is not intended to be operated by means of an external timer or separate remote-control system.
7. The outer surface may get hot when the appliance is operating.
8. Let the appliance cool down in a location out of reach of children or persons with limited mental abilities before cleaning.
9. The bread may burn, therefore do not use the toaster near or below combustible material, such as curtains.
10. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
11. Before connecting the toaster to the power, check the voltage shown on the appliance corresponds with the voltage in your home. If it doesn't, contact your local store.
12. This appliance is classified as protection class I and must be connected to a protective ground.
13. To avoid fire, electric shock, or injury, never immerse the toaster, cord, or plug in water or liquid.
14. Keep away from harsh or abrasive cleaning agents or solvents.
15. Remove all protective wrapping prior to use.
16. Do not use if the appliance, cord or plug is damaged.
17. Always place on a firm, level surface, out of reach of children.
18. If the toast starts to smoke press cancel immediately.
19. Avoid toasting food that has been buttered or covered with toppings.
20. The cord shouldn't hang over the edge of a table or counter, or touch a hot surface.
21. Keep away from hot gas, electric burners and ovens.
22. Don't attempt to dislodge food while the toaster is in use. After use, take the bread out carefully to avoid injury. If the bread is jammed, unplug the toaster

3

23. Be sure not to damage the internal mechanism or heating elements when removing bread.
24. Unplug when not in use and before cleaning.
25. Do not use attachments not recommended by the manufacturer.

26. Don't use the toaster for anything other than its intended use.

27. Please don't dismantle. If a fault occurs have the toaster inspected in a qualified repair shop or return to us at Asda. To remove any crumbs from the toaster, slide out the crumb tray from under the toaster, empty and replace in the toaster before using it again.

28. Do not leave the toaster unattended while in use.
29. Do not leave the toaster unattended during operation.
30. The power consumption is 0 W in the off mode.

The period after which the equipment reaches automatically off mode is less than 1 min.




This symbol on the toaster is a safe, cautionary symbol for hot surfaces accessible to users. This symbol alerts you to hot hazards that you can be injured from.

CAUTION, hot surface. The surface can be hot and should not be touched without taking care.

You should have


4-slice toaster



4


4. Press the levers down until they lock into place and the Cancel lights are illuminated (this will only happen when the toaster is switched on).

Once the bread has been toasted the levers will automatically spring back up and can be lifted slightly further upward to easily remove the toast.




5. If you want to stop toasting at any point, just press the Cancel buttons and the levers will spring up.

Please don't try to manually force them up as this could damage the toaster.




6. Frozen bread can still be toasted. Simply set the browning control dials to the desired position, push the levers down and press the Defrost buttons so they illuminate as well as the cancel button.



7. For reheating cold toast, just place the toast into the bread slots, push the levers down and press the Reheat buttons.

You don't need to use the browning control dials as the reheat mode has a set time.



9


How to...

...use your toaster


Please note

You don't need to press down both levers when only inserting bread into one side of the toaster.


1. Check both of the crumb trays at the back of the toaster are fully inserted, then slot up to four slices of bread into the bread slots.



2. Plug the toaster into the power socket and switch it on.



3. Set the control dial to your desired setting, 1 being the lowest and 6 being the highest.




You may want to start at 3 and then adjust to your taste (bread may be slightly more toasted when only toasting one slice or when using for extended periods of time).

8

How to...

...recognise the parts of your toaster



5


How to...

...prepare your toaster before first use


Please note

Oil or manufacturing residue may remain on the heat elements, so it's usual for the toaster to emit an odour when used for the first few times. This is perfectly normal and can be prevented by following these quick steps:


1. Slot the plug into the mains socket and turn the power on.



2. Set both of the control dials to number 6.




3. Push both levers down until they lock into place.




The smoke emitted from the toaster could set the smoke alarm off, so please do open a window beforehand.

6


4. Wait for both levers to pop upwards.



5. Allow the toaster to cool and then repeat.



6. When there is no more odour the toaster is ready to use.



Please note

The toaster allows you high lift the toast after pressing the cancel button. Simply lift the lever up. Do not touch the bread whilst checking. Releasing the lever will drop the toast back into the slots.

7